

NutriCulture Live-Dead Cell (Calcein AM/PI) Staining Kit

Troubleshooting Guide

500 tests (96-well plate format)

Cat No: LDC500

Use this guide for common Calcein AM/PI staining problems. The datasheet emphasizes -20°C light-protected storage, protection of Calcein AM from moisture, fresh same-day staining solution, cell-line-specific concentration optimization, PBS washing to remove extracellular esterases, and defined fluorescence channels for live (green) and dead (red) cells.

Before You Start - Quick Checks

1. Store at -20°C protected from light and protect Calcein AM from moisture; use desiccant for aliquots.
2. Prepare staining solution fresh for each experiment and use it within one day.
3. Optimize probe concentration for each cell line and use the lowest concentration that gives adequate fluorescence.
4. For the standard 5 mL staining solution, add 5 uL Calcein AM and 15 uL PI to 5 mL 1x PBS.
5. Wash cells 2-3 times with 1x PBS before staining to remove esterases from culture medium.
6. Protect staining mixtures and stained samples from light.

Problem	Most likely cause	Recommended action
Live-cell green fluorescence is weak	Calcein AM concentration may be too low, the staining solution may be old, or cells may export the dye.	Prepare fresh same-day staining solution, optimize Calcein AM within the datasheet range, and consider the datasheet note that living cells may discharge the dye.
Dead-cell red fluorescence is weak	PI concentration may be below the optimal range for the cell type.	Optimize PI within the datasheet range while keeping the rest of the staining conditions constant.
Background fluorescence is high	Probe concentration may be higher than necessary.	Perform the recommended concentration gradient and use the lowest probe concentration that provides adequate separation.
Unexpected staining occurs after prolonged aqueous storage	Calcein AM is poorly stable in aqueous solution.	Prepare staining solution immediately before each experiment and use it within one day.
Calcein AM stock performance declines during storage	The stock may have been exposed to moisture or light.	Store at -20°C protected from light and moisture. Keep aliquots in a desiccator or airtight secondary container with desiccant.
Flow-cytometry cell suspension is outside the recommended range	Cell density may be too low or too high for the protocol.	Prepare cells in 1x PBS at 5×10^5 to 1×10^6 cells/mL.
Flow-cytometry staining is weak	Staining volume or time may not match the protocol.	Add 100 uL staining solution to 200 uL cell suspension, mix, and incubate at 37°C for 15 minutes protected from light; extend to 30 minutes if needed.

Table continues on next page.

NutriCulture Live-Dead Cell (Calcein AM/PI) Staining Kit

Troubleshooting Guide (continued)

Problem	Most likely cause	Recommended action
Flow samples cannot be analyzed immediately	Delay may reduce comparability.	Protect from light and store at 4°C for detection within 2 hours, as recommended.
Microscopy staining is weak or uneven	Working-solution volume or incubation time may not match the plate format.	Use 200 uL per well in a 24-well plate or 500 uL per well in a 6-well plate and incubate at 37°C for 10-30 minutes.
Staining solution was prepared in basic medium rather than PBS	The datasheet requires a longer staining interval for this preparation.	When staining solution is prepared with basic medium, extend staining to 30-60 minutes and add PI 10 minutes before the end of the reaction.
Live/dead channels are confused	The fluorescence channels may be assigned incorrectly.	Use Calcein green fluorescence at Ex/Em 494/517 nm and PI red fluorescence at Ex/Em 535/617 nm.
Staining differs between cell lines	Optimal probe concentration can vary by cell line.	Perform the recommended concentration screening for each new cell line before fixing a standard condition.
Extracellular esterase causes unreliable Calcein staining	Culture-medium esterases may not have been removed.	Wash cells 2-3 times with 1x PBS before staining.
Probe appears to enter organelles excessively	Staining temperature can influence probe behavior.	The datasheet notes that room-temperature staining can reduce the side effect of fluorescent-probe penetration into organelles, although 37°C shortens staining time.

Still having trouble? Recheck storage against light and moisture, prepare fresh same-day staining solution, wash cells 2-3 times with PBS, optimize Calcein AM/PI concentration for the cell line, use the stated cell density and staining times, and analyze in the correct green/red fluorescence channels.